

## How to install a LAI S580-P hasp over an older porvene hasp on a porvene Door

porvene hasps are known to be easily cut to Gain access to storage units.

Sometimes you need a stronger hasp that will fit the porvene door corrugation.

LAI has the perfect fit for your door, the S580-P hasp. Here is how you add one to your door.

Parts needed:

- S580-P Hasp
- Drill
- Step Drill Bit
- Reciprocal Saw
- Metal Blade
- Socket wrench w/ extension
- 1/16" socket



Select a spot above existing broken hasp

Push hasp into door opening until hasp is at edge of curtain.

Mark mounting holes and drill with step bit, being careful not to drill too big a hole. Or you can use a 1/4" bit.

Open door to get inside or have another person inside to attach nuts to the mounting bolts.



With door closed, mark where the tongue of the hasp will be, above and below tongue.

Open door completely and get step drill and drill track above the upper mark, drill another hole about 2" down for the lower part of the track.

Make sure there isn't too much play in slot so door is secure.

Use the Reciprocal Saw to cut vertically down the side to connect the two circles.



Roll down the door and move the tab to make sure it fits in the hole.

Always dry fit items before drilling and cutting to make sure they are accurate.

You can drill out the two tab rivets, slide out the cross rod and paint the porvene hasp the door color to camouflage the old hasp.

